Assembling Whoopee Deux and Whoopee Un for the Bike Friday Haul-a-Day Elite & Ever-e-Day

(December 2023 version)



Items:

2 – 23 inch tubes (for Haul-a-Day & Ever-e-Day)

2 – 23 inch (Haul-a-Day) or 20 inch (Ever-e-Day) tubes

2 - Pair of braces (1- L & 1- R)

Bar Tape

Hardware provided:

Otv 2 - M6x12 SS BHCS

Qty 2 - M6x25 SS BHCS

Qty 4 – M6 SS Nyloc Nut

Qty 4 - M6x20 SS SHCS



Take off rack top plate, then install braces as shown <u>under</u> the rack top plate.


Tighten the bolts until they are finger-tight.

Notice direction of the plate/feet. The Ever-e-Day has the front braces turned back to give 3 inches more clearance for bike rider's legs.





Install (23 inch for HaD, 20 inch for EVD) tubes in front and back of rear rack. The tubes should have 1 inch showing outside of the clamp.







Install 23 inch tubes on either side of the rear rack.



- Tighten all the bolts (5-7nm)
- 5. Finish by adding handle bar tape (included) over the 4 silver tubes or padding of your choice.

